
Test Multifrequencies

TMF messages

TMF0000	Program identifier.
TMF0001	Invalid input, number of chars in one field are greater than 4.
TMF0002	Invalid input, garbage datatype.
TMF0003	Invalid input, command field unknown.
TMF0004	Invalid input, too many parameters.
TMF0005	Last command is still in progress.
TMF0006	Invalid TN.
TMF0007	Invalid DOD trunk.
TMF0008	Trunk is busy or disabled.
TMF0009	Invalid TN. SHLF out-of-range (0 to 3).
TMF0010	Invalid TN. Card out-of-range (1 to 10).
TMF0011	Invalid set TN.
TMF0012	Defined set is busy or disabled.
TMF0013	Package restricted, Overlay not allowed to load.
TMF0014	Signaling type not defined.
TMF0015	Signaling type already defined.
TMF0016	Command not valid for MFE signaling.

TMF0017	Trunk Busy - DSI Timing.
TMF0018	Use loop and channel for digital loop TN.
TMF0019	Invalid Digital Loop TN.